

SO-ARM101 开源 6 轴机械臂使用文档

1. 虚拟机 linux 环境配置

虚拟机下载安装步骤（步骤 1-3.6）：

https://blog.csdn.net/m0_37383484/article/details/138029827

ubuntu22.04 系统镜像文件下载链接：<https://releases.ubuntu.com/jammy/ubuntu-22.04.5-desktop-amd64.iso>

2. 机械臂组装

请在输入舵机 ID 后观看组装视频组装，提前组装会导致 ID 输入时，接线困难

3. miniconda3 环境

3.1 miniconda3 安装

按 CTRL+ALT+T 打开终端，输入更新软件包指令

```
sudo apt update && sudo apt upgrade
```

```
Do you want to continue? [Y/n]
```

遇到该界面按 enter 表示继续

终端输入下载安装包：

```
wget https://mirrors.tuna.tsinghua.edu.cn/anaconda/miniconda/Miniconda3-py310\_23.11.0-2-Linux-x86\_64.sh
```

运行安装：bash ‘/home/主机名/Miniconda3-py310_23.11.0-2-Linux-x86_64.sh’

按下 enter 键表示确定（主机名是指自己的虚拟机主机名，例如此处作者使用的是 host）

```
host@111:~$ bash '/home/host/Miniconda3-py310_23.11.0-2-Linux-x86_64.sh'
```

```
Welcome to Miniconda3 py310_23.11.0-2
```

```
In order to continue the installation process, please review the license agreement.
```

```
Please, press ENTER to continue
```

```
>>>
```

```
=====
End User License Agreement - Miniconda
=====
```

```
Copyright 2015-2023, Anaconda, Inc.
```

```
All rights reserved under the 3-clause BSD License:
```

```
This End User License Agreement (the "Agreement") is a legal agreement between you and Anaconda, Inc. ("Anaconda") and governs your use of Miniconda.
```

```
Subject to the terms of this Agreement, Anaconda hereby grants you a non-exclusive, non-transferable license to:
```

- * Install and use the Miniconda,
- * Modify and create derivative works of sample source code delivered in Miniconda subject to the Terms of Service for the Repository (as defined hereinafter) available at <https://www.anaconda.com/terms-of-service>, and
- * Redistribute code files in source (if provided to you by Anaconda as source) and binary forms, with or without modification subject to the requirements set forth below.

```
Anaconda may, at its option, make available patches, workarounds or other updates.
--More--
```

按↓键，直到出现该界面后输入 yes，再按 enter

```
The following packages listed on https://www.anaconda.com/cryptography are included in the Repository accessible through Miniconda that relate to cryptography.
```

```
Last updated March 21, 2022
```

```
Do you accept the license terms? [yes|no]
```

```
>>>
```

按 enter 确认

```
Do you accept the license terms? [yes|no]
```

```
>>> yes
```

```
Miniconda3 will now be installed into this location:
/home/host/miniconda3
```

- Press ENTER to confirm the location
- Press CTRL-C to abort the installation
- Or specify a different location below

```
[/home/host/miniconda3] >>>
```

输入 yes，再按 enter

```
conda config --set auto_activate_base false

You can undo this by running `conda init --reverse $SHELL`? [yes|no]
[no] >>>
```

输入 conda --version 出现版本号即为成功

```
host@111:~$ conda --version
conda 23.11.0
```

3.2 miniconda 换源

关闭终端重新按 ctrl+alt+T 打开新终端，输入 conda config --set show_channel_urls yes 后输入 gedit .condarc

```
(base) host@111:~$ conda config --set show_channel_urls yes
(base) host@111:~$ gedit .condarc
□
```

输入以下源通道后按 ctrl+s 保存后退出

channels:

- defaults

show_channel_urls: true

default_channels:

- <https://mirrors.tuna.tsinghua.edu.cn/anaconda/pkg/main>


- <https://mirrors.tuna.tsinghua.edu.cn/anaconda/pkg/r>

- <https://mirrors.tuna.tsinghua.edu.cn/anaconda/pkg/msys2>

custom_channels:

conda-forge: <https://mirrors.tuna.tsinghua.edu.cn/anaconda/cloud>

pytorch: <https://mirrors.tuna.tsinghua.edu.cn/anaconda/cloud>

A screenshot of a text editor window titled *.condarc. The window has a menu bar with 'Open', 'Save', and window control buttons. The content of the file is as follows:

```
1 channels:
2 - defaults
3 show_channel_urls: true
4 default_channels:
5 - https://mirrors.tuna.tsinghua.edu.cn/anaconda/pkg/main
6 - https://mirrors.tuna.tsinghua.edu.cn/anaconda/pkg/r
7 - https://mirrors.tuna.tsinghua.edu.cn/anaconda/pkg/msys2
8 custom_channels:
9 conda-forge: https://mirrors.tuna.tsinghua.edu.cn/anaconda/cloud
10 pytorch: https://mirrors.tuna.tsinghua.edu.cn/anaconda/cloud
```

终端输入 `conda clean -i` 清除缓存

```
(base) host@111:~$ gedit .condarc
(base) host@111:~$ conda clean -i
```

输入 y, 再按 enter

```
Will remove 1 index cache(s).
Proceed ([y]/n)? y
```

3.3 虚拟环境配置

终端输入, 创建虚拟环境:

`conda create -n lerobot python=3.10.18 ffmpeg=7.1.1 -c conda-forge`

```
(base) host@111:~$ conda create -n lerobot python=3.10.18 ffmpeg=7.1.1 -c conda-forge
Channels:
 - conda-forge
 - defaults
Platform: linux-64
Collecting package metadata (repodata.json): done
Solving environment: done
```

输入 y, 再按 enter

```
xorg-libxfixes      conda-forge/linux-64::xorg-libxfixes-6.0.2-hb03c661_0
xorg-libxrandr      conda-forge/linux-64::xorg-libxrandr-1.5.4-hb9d3cd8_0
xorg-libxrender      conda-forge/linux-64::xorg-libxrender-0.9.12-hb9d3cd8_0
xorg-libxscrsaver    conda-forge/linux-64::xorg-libxscrsaver-1.2.4-hb9d3cd8_0
zstd                 conda-forge/linux-64::zstd-1.5.7-h3691f8a_5

Proceed ([y]/n)?
```

终端输入 `conda env list`, 出现 `lerobot` 则创建成功

```
(base) host@111:~$ conda env list
# conda environments:
#
base                *  /home/host/miniconda3
lerobot              /home/host/miniconda3/envs/lerobot
```

终端输入 `conda activate lerobot` 进入环境, 主机名前出现 `lerobot` 或 `base` 改为 `lerobot` 则进入成功

```
(base) host@111:~$ conda activate lerobot
(lerobot) host@111:~$
```

下载并移动 `lerobot` 程序源码(压缩包中有):

将源码文件拖入或复制粘贴入虚拟机(放置在共享文件夹也可以), 不能复制请重新安装 `open-vm-tools-desktop`

然后使用 `unzip lerobot.zip` 解压

```
(base) host@111:~/Downloads$ unzip lerobot.zip
Archive:  lerobot.zip
  creating:  lerobot/
  inflating:  lerobot/.dockerignore
  creating:  lerobot/.git/
  inflating:  lerobot/.git/config
  inflating:  lerobot/.git/description
  inflating:  lerobot/.git/HEAD
  inflating:  lerobot/.git/hooks/
```

输入 `cd lerobot` 进入文件夹, 再输入 `sudo apt install pip` 安装 `pip`

```
(base) host@111:~/lerobot$ sudo apt install pip
[sudo] password for host:
Reading package lists... Done
Building dependency tree... Done
Reading state information... Done
Note, selecting 'python3-pip' instead of 'pip'
The following additional packages will be installed:
  binutils binutils-common binutils-x86-64-linux-gnu
```

输入: `conda install ffmpeg=7.1.1 -c conda-forge`


```
(lerobot) host@111:~/lerobot$ conda install ffmpeg=7.1.1 -c conda-forge
Channels:
 - conda-forge
 - defaults
Platform: linux-64
Collecting package metadata (repodata.json): done
Solving environment: done
```

终端输入安装依赖包和驱动:

```
pip install -e ".[feetech]" -i https://pypi.tuna.tsinghua.edu.cn/simple
```

```
(base) host@111:~/lerobot$ pip install -e ".[feetech]" -i https://pypi.tuna.tsinghua.edu.cn/simple
Looking in indexes: https://pypi.tuna.tsinghua.edu.cn/simple
Obtaining file:///home/host/lerobot
  Installing build dependencies ... done
  Checking if build backend supports build_editable ... done
  Getting requirements to build editable ... done
  Preparing editable metadata (pyproject.toml) ... done
Collecting datasets<=3.6.0,>=2.19.0
  Downloading https://pypi.tuna.tsinghua.edu.cn/packages/20/34/a08b0ee99715eaba18cbe19a71f7b5e2425c2718ef96007c325944a1152/datasets-3.6.0-py3-none-any.whl (491 kB)
  491.5/491.5 kB 2.2 MB/s eta 0:00:00
```

出现路径则安装成功

```
(lerobot) host@111:~/lerobot$ which ffmpeg
/home/host/miniconda3/envs/lerobot/bin/ffmpeg
```

安装 torch 和 torchvision:

```
pip install torch==2.5.1 torchvision==0.21.10 --index-url
https://download.pytorch.org/whl/cu124
```

```
(lerobot) host@111:~/lerobot$ pip install torch==2.5.1 torchvision==0.20.1 --index-url https://download.pytorch.org/whl/cu124
Looking in indexes: https://download.pytorch.org/whl/cu124
Collecting torch==2.5.1
  Downloading https://download.pytorch.org/whl/cu124/torch-2.5.1%2Bcu124-cp310-cp310-linux_x86_64.whl (908.3 MB)
  908.3/908.3 MB ? 0:01:34
```

4. 舵机 id 发送

将 usb 线插入驱动板(从臂)并连接上 5V 电源适配器

插入 usb 后输入(如果没有检测到 usb, 请将 usb 线转动 180° 再插入):

```
python -m lerobot.find_port
```

```
(lerobot) host@111:~/lerobot$ python -m lerobot.find_port
Finding all available ports for the MotorsBus.
Ports before disconnecting: ['/dev/ttyACM0', '/dev/ttyprintk', '/dev/ttyS31', '/dev/ttyS30', '/dev/ttyS29', '/dev/ttyS28', '/dev/ttyS27', '/dev/ttyS26', '/dev/ttyS25', '/dev/ttyS24', '/dev/ttyS23', '/dev/ttyS22', '/dev/ttyS21', '/dev/ttyS20', '/dev/ttyS19', '/dev/ttyS18', '/dev/ttyS17', '/dev/ttyS16', '/dev/ttyS15', '/dev/ttyS14', '/dev/ttyS13', '/dev/ttyS12', '/dev/ttyS11', '/dev/ttyS10', '/dev/ttyS9', '/dev/ttyS8', '/dev/ttyS7', '/dev/ttyS6', '/dev/ttyS5', '/dev/ttyS4', '/dev/ttyS3', '/dev/ttyS2', '/dev/ttyS1', '/dev/ttyS0', '/dev/tty63', '/dev/tty62', '/dev/tty61', '/dev/tty60', '/dev/tty59', '/dev/tty58', '/dev/tty57', '/dev/tty56', '/dev/tty55', '/dev/tty54', '/dev/tty53', '/dev/tty52', '/dev/tty51', '/dev/tty50', '/dev/tty49', '/dev/tty48', '/dev/tty47', '/dev/tty46', '/dev/tty45', '/dev/tty44', '/dev/tty43', '/dev/tty42', '/dev/tty41', '/dev/tty40', '/dev/tty39', '/dev/tty38', '/dev/tty37', '/dev/tty36', '/dev/tty35', '/dev/tty34', '/dev/tty33', '/dev/tty32', '/dev/tty31', '/dev/tty30', '/dev/tty29', '/dev/tty28', '/dev/tty27', '/dev/tty26', '/dev/tty25', '/dev/tty24', '/dev/tty23', '/dev/tty22', '/dev/tty21', '/dev/tty20', '/dev/tty19', '/dev/tty18', '/dev/tty17', '/dev/tty16', '/dev/tty15', '/dev/tty14', '/dev/tty13', '/dev/tty12', '/dev/tty11', '/dev/tty10', '/dev/tty9', '/dev/tty8', '/dev/tty7', '/dev/tty6', '/dev/tty5', '/dev/tty4', '/dev/tty3', '/dev/tty2', '/dev/tty1', '/dev/tty0', '/dev/tty']
Remove the USB cable from your MotorsBus and press Enter when done.
```

拔出 usb 后按 enter, `/dev/ttyACM0` 为从臂 usb 驱动名 (usb 默认为先后顺序排列驱动名, 一般先插为 `/dev/ttyACM0`, 第二个则为 `/dev/ttyACM1`, 以此类推, 请注意, 驱动名也有可能是 `/dev/ttyUSB0`, 如果是这样, 请把命令中 ACM 部分改为 USB)

```
Remove the USB cable from your MotorsBus and press Enter when done.

The port of this MotorsBus is '/dev/ttyACM0'
Reconnect the USB cable.
```

终端输入给予驱动端口权限: `sudo chmod 666 /dev/ttyACM0`

输入主臂 id 则输入(红色部分为需要根据驱动名更改的部分):

```
lerobot-setup-motors \
  --teleop.type=sol01_leader \
  --teleop.port=/dev/ttyACM0
```

输入从臂 id 则输入:

```
lerobot-setup-motors \
  --teleop.type=sol01_follower \
  --teleop.port=/dev/ttyACM0
```

按从高到低分别连接六个舵机(夹爪->底盘旋转)，每次确认连接好舵机线和 usb 线以及数据线后按 enter 即可赋 id，**赋 id 时舵机与舵机之间禁止连接，一次只可输入一个舵机 ID 号**

```
(lerobot) host@111:~/lerobot$ lerobot-setup-motors --robot.type=so101_follower
er --robot.port=/dev/ttyACM0
Connect the controller board to the 'gripper' motor only and press enter.
'gripper' motor id set to 6
Connect the controller board to the 'wrist_roll' motor only and press enter.
'wrist_roll' motor id set to 5
Connect the controller board to the 'wrist_flex' motor only and press enter.
'wrist_flex' motor id set to 4
Connect the controller board to the 'elbow_flex' motor only and press enter.
'elbow_flex' motor id set to 3
Connect the controller board to the 'shoulder_lift' motor only and press enter.
'shoulder_lift' motor id set to 2
Connect the controller board to the 'shoulder_pan' motor only and press enter.
'shoulder_pan' motor id set to 1
```

Tips: 从臂赋 id 号过程同上

5. 校准机械臂

```
sudo chmod 666 /dev/ttyACM*
rm -rf ~/.cache/huggingface/lerobot/calibration/robots
rm -rf ~/.cache/huggingface/lerobot/calibration/teleoperators

lerobot-calibrate \
  --robot.type=so101_follower \
  --robot.port=/dev/ttyACM0 \
  --robot.id=my_awesome_follower_arm
lerobot-calibrate \
  --teleop.type=so101_leader \
  --teleop.port=/dev/ttyACM1 \
  --teleop.id=my_awesome_leader_arm
```

将机械臂各关节调至中间位置，按下 enter，然后活动每个关节直至最大最小范围后按 enter 保存(如果发现 usb 连接不上，请把 usb 反过来插)

```
(lerobot) seeed@seeed-KuangshiG16-PRO-Series-GM6PQ7Q:~/lerobot$ python -m lerobot
t.calibrate --robot.type=so101_follower --robot.port=/dev/ttyACM0 --robot
t.id=my_awesome_follower_arm
INFO 2025-08-09 14:54:41 calibrate.py:73 {'robot': {'calibration_dir': None,
  'cameras': {},
  'disable_torque_on_disconnect': True,
  'id': 'my_awesome_follower_arm',
  'max_relative_target': None,
  'port': '/dev/ttyACM0',
  'use_degrees': False},
  'teleop': None}
INFO 2025-08-09 14:54:41 follower.py:104 my_awesome_follower_arm S0101Follower c
onnected.
INFO 2025-08-09 14:54:41 follower.py:121
Running calibration of my_awesome_follower_arm S0101Follower
Move my_awesome_follower_arm S0101Follower to the middle of its range of motion
and press ENTER....
```


6. 遥感控制

该指令为从臂 usb 驱动名为/dev/ttyACM0,主臂 usb 驱动名为/dev/ttyACM1, 如果不同请更改指令 port 部分

```
sudo chmod 666 /dev/ttyACM*
lerobot-teleoperate \
  --robot.type=s0101_follower \
  --robot.port=/dev/ttyACM0 \
  --robot.id=my_awesome_follower_arm \
  --teleop.type=s0101_leader \
  --teleop.port=/dev/ttyACM1 \
  --teleop.id=my_awesome_leader_arm
```

```
(lerobot) host@111:~/lerobot$ lerobot-teleoperate --robot.type=s0101_follower
--robot.port=/dev/ttyACM0 --robot.id=my_awesome_follower_arm --teleop.type=s0101_leader
--teleop.port=/dev/ttyACM1 --teleop.id=my_awesome_leader_arm
INFO 2025-12-04 11:13:56 eoperate.py:135 {'display_data': False,
'fps': 60,
'robot': {'calibration_dir': None,
'cameras': {},
'disable_torque_on_disconnect': True,
'id': 'my_awesome_follower_arm',
'max_relative_target': None,
'port': '/dev/ttyACM0',
'use_degrees': False},
'teleop': {'calibration_dir': None,
'id': 'my_awesome_leader_arm',
'port': '/dev/ttyACM1',
'use_degrees': False},
'teleop_time_s': None}
INFO 2025-12-04 11:13:56 01_leader.py:82 my_awesome_leader_arm S0101Leader connected.
INFO 2025-12-04 11:13:56 follower.py:104 my_awesome_follower_arm S0101Follower connected.
```

做到这一步, 就可以开始通过控制主臂来控制从臂了, 如要关闭进程, 关闭 终端或 Ctrl+C 即可